

スマートフォンケース【ハードケース】 対応機種一覧

docomo
iPhone X / XS
iPhone XR
iPhone XS Max
iPhone7/8
iPhone7Plus/8Plus
iPhone6/6s
iPhone6Plus/6sPlus
iPhone5/5s/SE
iPhone5c
Xperia XZ3 SO-01L / SOV39
Xperia XZ2 SO-03K / SOV37 / 702SO
Xperia XZ2 Compact SO-05K
Xperia XZ2 Premium SO-04K / SOV38
Xperia XZ1 SO-01K / SOV36 / 701SO
Xperia XZ1 Compact SO-02K
Xperia XZ Premium SO-04J
Xperia XZs SO-03J / SOV35 / 602SO
Xperia XZ SO-01J / SOV34 / 601SO
Xperia Z1 SO-01F/SOL23
Xperia X Compact SO-02J
Xperia X Performance SO-04H/SOV33/502SO
Xperia A SO-04E
Xperia Z5 Premium SO-03H
Xperia Z5 SO-01H / SOV32 / 501SO
Xperia Z5 Compact SO-02H
Xperia Z4 SO-03G / SOV31 / 402SO
Xperia A4 SO-04G
Xperia Z3 SO-01G / SOL26 / 401SO
Xperia Z3 Compact SO-02G
Xperia Z2 SO-03F
Xperia A2 SO-04F
Xperia Z1f SO-02F
AQUOS Compact SH-02H / Xx2 mini 503SH
AQUOS EVER SH-02J
AQUOS EVER SH-04G
AQUOS PHONE EX SH-02F
AQUOS PHONE ZETA SH-06E
AQUOS PHONE ZETA SH-01F
AQUOS R2 SH-03K/SHV42/706SH
AQUOS R SH-03J / SHV39 / 604SH / 605SH
AQUOS sense2 SH-01L / SHV43 / SH-M08
AQUOS sense SH-01K / SHV40 / lite SH-M05
AQUOS ZETA SH-01H / Xx2 502SH
AQUOS ZETA SH-01G / SH-02G
AQUOS ZETA SH-03G
AQUOS ZETA SH-04F
AQUOS ZETA SH-04H/SERIE SHV34/Xx3 506SH
arrows Be F-04K
arrows Fit F-01H
ARROWS NX F-05F
ARROWS NX F-01F
arrows NX F-01J
arrows NX F-01K
ARROWS NX F-02G
arrows NX F-02H
ARROWS NX F-04G
ARROWS NX F-06E
arrows SV F-03H / M03 / M04 / Be F-05J
Galaxy S9 SC-02K / SCV38
Galaxy S9 Plus SC-03K / SCV39
Galaxy Feel SC-04J
Galaxy S8 SC-02J / SCV36
Galaxy S8 Plus SC-03J / SCV35
Galaxy S7 edge SC-02H / SCV33
Galaxy S6 edge SC-04G / SCV31 / 404SC
Galaxy Note8 SC-01K / SCV37
GALAXY Note Edge SC-01G / SCL24
GALAXY J SC-02F
GALAXY Active neo SC-01H
Galaxy S6 SC-05G
GALAXY S5 SC-04F
GALAXY S4 SC-04E
GALAXY SIII SC-03E
GALAXY SIII SC-06D
Google Pixel 3
Google Pixel 3 XL
Disney Mobile on docomo DM-02H
LG Style L-03K
らくらくスマートフォン4 F-04J
MONO MO-01J
MONO MO-01K
Nexus 5X

au
iPhone X / XS
iPhone XS Max
iPhone XR
iPhone7/8
iPhone7Plus/8Plus
iPhone6/6s
iPhone6Plus/6sPlus
iPhone5/5s/SE
iPhone5c
Xperia XZ3 SO-01L / SOV39
Xperia XZ2 SO-03K / SOV37 / 702SO
Xperia XZ2 Premium SO-04K / SOV38
Xperia XZ1 SO-01K / SOV36 / 701SO
Xperia XZs SO-03J / SOV35 / 602SO
Xperia XZ SO-01J / SOV34 / 601SO
Xperia Z5 SO-01H / SOV32 / 501SO
Xperia X Performance SO-04H/SOV33/502SO
Xperia Z4 SO-03G / SOV31 / 402SO
Xperia Z3 SO-01G / SOL26 / 401SO
Xperia ZL2 SOL25
Xperia Z1 SO-01F/SOL23
Xperia Z Ultra SOL24
AQUOS PHONE SERIE SHL22
AQUOS PHONE SERIE SHL23
AQUOS R2 SH-03K/SHV42/706SH
AQUOS R SH-03J / SHV39 / 604SH / 605SH
AQUOS R compact SHV41 / SH-M06
AQUOS sense2 SH-01L / SHV43 / SH-M08
AQUOS sense SH-01K / SHV40 / lite SH-M05
AQUOS SERIE SHV32
AQUOS SERIE mini SHV38 / Xx3 mini 603SH
AQUOS SERIE mini SHV33 / mini SH-M03
AQUOS SERIE mini SHV31
AQUOS PHONE SERIE mini SHL24
AQUOS SERIE SHL25
AQUOS U SHV35
ARROWS Z FJL22
AQUOS ZETA SH-04H/SERIE SHV34/Xx3 506SH
Galaxy S9 SC-02K / SCV38
Galaxy S9 Plus SC-03K / SCV39
Galaxy Note8 SC-01K / SCV37
Galaxy S8 SC-02J / SCV36
Galaxy S8 Plus SC-03J / SCV35
Galaxy S7 edge SC-02H / SCV33
Galaxy A8 SCV32
Galaxy S6 edge SC-04G / SCV31 / 404SC
GALAXY Note Edge SC-01G / SCL24
GALAXY S5 SCL23
DIGNO rafre KYV36
isai FL LGL24 / VL LGV31
isai vivid LGV32
Qua Phone KYV37
Qua phone PX LGV33
HTC J butterfly HTV31
HTC 10 HTV32
HTC U11 HTV33 / 601HT
HUAWEI P20 lite HWV32
URBANO V01 KYV31
URBANO V02 KYV34
URBANO V03 KYV38
TORQUE G02 KYV35

Softbank
iPhone X / XS
iPhone XR
iPhone XS Max
iPhone7/8
iPhone7Plus/8Plus
iPhone6/6s
iPhone6Plus/6sPlus
iPhone5/5s/SE
iPhone5c
iPhone4/4s
Xperia XZ3 SO-01L / SOV39
Xperia XZ2 SO-03K / SOV37 / 702SO
Xperia XZ1 SO-01K / SOV36 / 701SO
Xperia XZs SO-03J / SOV35 / 602SO
Xperia XZ SO-01J / SOV34 / 601SO
Xperia X Performance SO-04H/SOV33/502SO
Xperia Z5 SO-01H / SOV32 / 501SO
Xperia Z4 SO-03G / SOV31 / 402SO
Xperia Z3 SO-01G / SOL26 / 401SO
AQUOS Compact SH-02H / Xx2 mini 503SH
AQUOS CRYSTAL2 403SH / Y2 403SH
AQUOS CRYSTAL 305SH
AQUOS CRYSTAL X 402SH / Y 402SH
AQUOS PHONE Xx mini 303SH
AQUOS PHONE Xx 302SH
AQUOS R2 SH-03K/SHV42/706SH
AQUOS R SH-03J / SHV39 / 604SH / 605SH
AQUOS R compact SHV41 / SH-M06
AQUOS SERIE mini SHV38 / Xx3 mini 603SH
AQUOS Xx 304SH
AQUOS Xx 404SH / Y 404SH
AQUOS ZETA SH-01H / Xx2 502SH
AQUOS ZETA SH-04H/SERIE SHV34/Xx3 506SH
DIGNO J 704KC
DIGNO F 503KC / E 503KC
Galaxy S6 edge SC-04G / SCV31 / 404SC
Google Pixel 3
Google Pixel 3 XL
HUAWEI nova lite 2 704HW
Nexus 6P
シンプルスマホ4 704SH / 707SH

その他
iPod touch6
iPod touch5
AQUOS SERIE mini SHV33 / mini SH-M03
AQUOS CRYSTAL2 403SH / Y2 403SH
AQUOS CRYSTAL X 402SH / Y 402SH
AQUOS R compact SHV41 / SH-M06
AQUOS sense SH-01K / SHV40 / lite SH-M05
AQUOS Xx 404SH / Y 404SH
Android One S5
Android One S4
Android One 507SH
arrows SV F-03H / M03 / M04 / Be F-05J
DIGNO C 404KC
DIGNO F 503KC / E 503KC
DIGNO T 302KC
FREETEL Priori3S LTE
FREETEL SAMURAI MIYABI (FTJ152C)
Google Pixel 3
Google Pixel 3 XL
HTC U11 HTV33 / 601HT
HUAWEI nova lite 2 704HW
HUAWEI P10
HUAWEI P10 lite
HUAWEI P9
HUAWEI P9 lite
Nexus 6P
Nexus 5X
Nexus 6
Nexus 5 EM01L
SONY WALKMAN NW-A16/A17
Spray 402LG
STREAM S 302HW
ZenFone2 ZE551ML
ZenFone5 A500KL